

SEQUENCE OF CONSTRUCTION

- 1. Remove the existing hot mix asphalt surface.
- 2. Remove and replace full depth patches.
- 3. Replace hot mix asphalt surface.

PAVEMENT PATCHING FOR HOT MIX ASPHALT SURFACED PAVEMENT

GENERAL NOTES

1. The width of the full depth patch over a trench shall be 12 (300) wider on each side of the trench.

All dimensions are in inches (millimeters) unless otherwise noted.

01-	DI-97 RENUM. C-104.03, NEW REVISION BOX, R	REVISED NOTES T.	P.	STATE OF HIMMON	HOT MANY ACRUMENT CURRENCE PERMONAL CHER DATOUES	RTE	SEC	CTION COUNTY	Y SHE	ETS I	NO.
09-	15-05 REVISED DESIGNER NOTE	M.N	1.A.	STATE OF ILLINOIS	HOT MIX ASPHALT SURFACE REMOVAL OVER PATCHES	665	58 1	ON PEORIA	A 12	20	79
10-	6-06 REVISED TO 2007 SPEC.	M.	Α.	DEPARTMENT OF TRANSPORTATION				CONTRA	ACT NO	J. 684	٠70
					NOT TO SCALE CADD STD. 44010	1-D4 FED.	ROAD DIST. NO.	ILLINOIS FED. AID PROJECT			