

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

REVISIONS		ILLINOIS DEPARTMENT OF TRANSPORTATION	
NAME	DATE	ILLINOIS DEFARIMEN	NI UP IMANSFURIALIUN
R. SHAH	10/25/94		
R. SHAH	01/14/95		
R. SHAH	03/23/95	PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT	
R. SHAH	04/24/95		
A. HOUSEH	03/15/96		
A. ABBAS	03/21/97		
A. ABBAS	01/20/98		
ART ABBAS	04/27/98	COME VERT. NOME	
R, BORO	01/01/07	SCALE: VERT. NONE	DRAWN BY
			CHECKED BY

Of DATE = 3/5/2007 LE NAME = K:\distad\bd22.dgn OT SCALE = 50.000 // IN, FR NAME = bauardi

BD400-04 (BD-22)