



SEQUENCE OF CONSTRUCTION

1. Remove the existing hot mix asphalt surface.
2. Remove and replace full depth patches.
3. Replace hot mix asphalt surface.

PAVEMENT PATCHING FOR
HOT MIX ASPHALT SURFACED PAVEMENT

GENERAL NOTES

1. The width of the full depth patch over a trench shall be 12 (300) wider on each side of the trench.

All dimensions are in inches (millimeters) unless otherwise noted.

01-01-97	RENUM. C-104.03, NEW REVISION BOX, REVISED NOTES	T.P.			STATE OF ILLINOIS DEPARTMENT OF TRANSPORTATION	HOT MIX ASPHALT SURFACE REMOVAL OVER PATCHES	F.A. RTE.	SECTION	COUNTY	TOTAL SHEETS	SHEET NO.	
09-15-05	REVISED DESIGNER NOTE	M.M.A.										59
10-16-06	REVISED TO 2007 SPEC.	M.A.										
						NOT TO SCALE	CADD STD. 440101-D4		FED. ROAD DIST. NO. ILLINOIS FED. AID PROJECT CONTRACT NO.			