

## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

REVISIONS		ILLINOIS DE
NAME	DATE	ILLINOIS DE
R. SHAH	10/25/94	
R. SHAH	01/14/95	
R. SHAH	03/23/95	PAVEM
R. SHAH	04/24/95	
A. HOUSEH	03/15/96	Г
A. ABBAS	03/21/97	
A. ABBAS	01/20/98	
ART ABBAS	04/27/98	SCALE, VERT, NONE

EPARTMENT OF TRANSPORTATION

MENT PATCHING FOR HMA SURFACED PAVEMENT

CHECKED BY BD400-04 (BD-22)