



SEQUENCE OF CONSTRUCTION

- 1. Remove the existing hot mix asphalt surface.
- 2. Remove and replace full depth patches.
- 3. Replace hot mix asphalt surface.

Existing hot mix asphalt

PAVEMENT PATCHING FOR HOT MIX ASPHALT SURFACED PAVEMENT

GENERAL NOTES

1. The width of the full depth patch over a trench shall be 12 wider on each side of the trench.

All dimensions are in inches unless otherwise noted.

USER NAME = Eric.Thomas	DESIGNED -	REVISED -		HOT MIX ASPHAL	OVED DATCHES	F.A.	SECTION	COUNTY	SHEETS	SHEET			
	DRAWN -	REVISED -	STATE OF ILLINOIS	HOT MIX ASPHALT SURFACE REMOVAL OVER PATCHES					1012.			OHEETO	140.
	CHECKED -	REVISED -	DEPARTMENT OF TRANSPORTATION							DISTRICT 4 DETAIL NO. 440101 (T NO.	
PLOT DATE = 12/7/2022	DATE -	REVISED -		SCALE: NOT TO SCALE SHEET	OF	SHEETS	STA.	TO STA.		ILLINOIS FED. A	AID PROJECT		