

SCHEDULE OF QUANTITIES (NORTH SIDE)

SIDEWALK REMOVAL 516 SQ FT P.C.C SIDEWALK, 5 INCH, SPECIAL 671 SQ FT PROTECTIVE COAT 86 SQ YD CONCRETE PAVERS 38.5 SQ FT BUS SHELTER 1 EACH TRASH RECEPTACLES 1 EACH FURNISH AND PLACE TOPSOIL, 4" 70 SQ YD SODDING 70 SQ YD FERTILIZER NUTRIENT 1 POUND INLET FILTERS 1 EACH MANHOLES TO BE ADJUSTED 1 EACH

SCHEDULE OF QUANTITIES (SOUTH SIDE)

SIDEWALK REMOVAL 460 SQ FT P.C.C. SIDEWALK, 5 INCH, SPECIAL 524 SQ FT PROTECTIVE COAT 69 SQ YD 38.5 SQ FT CONCRETE PAVERS BUS SHELTER 1 FACH TRASH RECEPTACLES 1 EACH FURNISH AND PLACE TOPSOIL, 4" 110 SQ YD SODDING 110 SQ YD FERTILIZER NUTRIENT 2 POUND INLET FILTERS 1 EACH

ILLINOIS DEPARTMENT OF TRANSPORTATION

BUS SHELTER INSTALLATION PLAN
NORTHWEST AND SOUTHWEST CORNERS OF
DEVON AVENUE AND ARTHUR AVENUE

HORIZ.: 20 0
SCALE IN FEET

DATE: 12/1/06 DESIGNED BY: DJK CHECKED BY: JRV