



SYMBOLS

- Work Area
- Impact Attenuator
- Temporary Concrete Barrier
- Temporary Concrete Barrier

NOTES
 Refer to Highway Standards 701432 in conjunction with this sheet for exact placement of traffic management devices and other clarifications as construction staging symbols and dimensioning were duplicated off of this standard. Traffic staging sequence shall be at the discretion of the Engineer for given field applications. All barricades, drums and markers shall be as shown on the standard.

FILE NAME = 11116.dgn	USER NAME = hudselsonne	DESIGNED -	REVISED -
		DRAWN -	REVISED -
	PLOT SCALE = 1/80.0000' / IN.	CHECKED -	REVISED -
	PLOT DATE = 1/29/2010	DATE -	REVISED -

**STATE OF ILLINOIS
 DEPARTMENT OF TRANSPORTATION**

S.N. 090-0110 STAGING (WB IL 116)

SCALE: SHEET NO. OF SHEETS STA. TO STA.

F.A.P. RTE. 673	SECTION ..	COUNTY TAZE/WOOD	TOTAL SHEETS 60	SHEET NO. 32
CONTRACT NO. 68920			ILLINOIS FED. AID PROJECT	

** 101RS-3; 102RS-4; 103RS-4; 104RS-7