

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

1	FILE NAME =	USER NAME = smithkI	DESIGNED - R. SHAH	REVISED - A. ABBAS 01-20-98				
	Wi\diststd\22x34\bd22idgn		DRAWN -	REVISED A. ABBAS 04-27-98		STATE OF ILLINOIS		
15 1		PLOT SCALE = 50.000 // IN.	CHECKED -	REVISED - R. BORO 01-01-07]	DEPARTMENT OF TRANSPORTATION		
4.4		PLOT, DATE = 4/3/2008	DATE - 10-25-94	REVISED - R. BORO 09-04-07			SCALE: NONE	SHEET
		And the second of the second o		The second secon				