



NOTE:
 INSTALL 4" PIPE UNDERDRAIN BENEATH OUTER EDGE OF CURB AND GUTTER AT A DEPTH OF 30" BELOW TOP OF P.C.C. PAVEMENT AT OUTER EDGE. USE PIPE UNDERDRAIN SPECIAL AS OUTLET TO CONNECT PIPE UNDERDRAIN TO CONCRETE HEADWALL AT STA. 99+00, STA. 106+20 AND STA. 109+00 OR AS DIRECTED BY THE RESIDENT ENGINEER.

FILE NAME =	USER NAME = kellers	DESIGNED -	REVISED - 3/16/11 SK	STATE OF ILLINOIS DEPARTMENT OF TRANSPORTATION	EXIST. & PROP. DRAINAGE & UTILITY PLAN IL. RTE. 59 AT U.S. RTE. 20			F.A.P. RTE. 338	SECTION 7 HB-K-N	COUNTY COOK	TOTAL SHEETS 82	SHEET NO. 28
ct:\pw_work\pwwork\kellers\d0156271\p142349-shd-drain.dgn	shd-drain.dgn	DRAWN -	REVISED -		SCALE: 1"=50'	SHEET NO. OF SHEETS	STA. TO STA.	CONTRACT NO. 60K62				
PLOT SCALE = 50.0000' / IN.		CHECKED -	REVISED -		ILLINOIS FED. AID PROJECT							
PLOT DATE = 3/16/2011		DATE -	REVISED -									