



- \* Cut bars and use in opposite end of culvert. See Cut Diagram on Sheet 4.
  - \*\* a20 bars in skew portion of slab shall be ordered full length & cut to fit. Balance of bar to be used in opposite end of culvert.
- For Elevation View & Section A-A, see Sheet 3.  
 For Section Thru Wingwall, Headwall Details & Bill of Material, see Sheet 4.

**SHOWING REINFORCEMENT**

**SHOWING OUTLINES**

**PARTIAL PLAN**

FILE NAME = ...D264987-2051-002-Culvert-11.dgn	USER NAME = SAW	DESIGNED - JLA	REVISIONS -	<b>STATE OF ILLINOIS DEPARTMENT OF TRANSPORTATION</b>	<b>BOX CULVERT PLAN IL 173 OVER WILLOW CREEK TRIBUTARY</b>	F.A.P. RTE. = 303	SECTION = 129K-1	COUNTY = WINNEBAGO	TOTAL SHEETS = 401	SHEET NO. = 273	
PLOT SCALE = 0:2.0000 ' / IN.	DRAWN - SAW	CHECKED - JLA	REVISIONS -			S.N. 101-2051		CONTRACT NO. 64987		ILLINOIS FED. AID PROJECT	
PLOT DATE = 10/29/2010	CHECKED - JLA	REVISIONS -	REVISIONS -			SHEET NO. 2 OF 6 SHEETS					