



**KEY FOR EARTHWORK**  
 UC = UNCLASSIFIED CUT  
 CF = COMPACTED FILL  
 UF = UNCOMPACTED FILL

END TXWY B EARTHWORK, SKEW STA. 186+58.72  
 = MATCH LINE, 260' LEFT OF RNWY 31 CENTERLINE

REMOVE 1' OF EXTG. SOILS &  
 INSTALL 2' OF ROCK BACKFILL

AHEAD: UC=0 CF=0 UF=0  
 BACK: UC=55 CF=416 UF=261

TAXIWAY B CROSS SECTIONS, STA 186+58.72 TO STA 187+50

:\\airport\057031\Sections.dwg, 6/28/2006 11:03:05 AM, jeffm