



- LEGEND**
- ◆ - TEMPORARY DITCH CHECK
 - ◆ - INLET & PIPE PROTECTION
 - - PERIMETER EROSION BARRIER
 - ▨ - TEMPORARY EROSION CONTROL SEEDING

TEMPORARY EROSION CONTROL ITEMS SCHEDULE

LOCATION	TEMPORARY EROSION CONTROL			
	TEMPORARY EROSION CONTROL SEEDING POUND	TEMPORARY DITCH CHECKS FOOT	PERIMETER EROSION BARRIER FOOT	INLET & PIPE PROTECTION EACH
STA. 1075+00 TO STA. 18+70 LT.	50			
STA. 1075+00 TO STA. 18+70 RT.	70			
STA. 1085+00 LT. & RT.		30		
STA. 1086+00 LT. & RT.		30		
STA. 1088+00 RT.		15		
STA. 1088+50 RT.		15		
STA. 1090+00 LT. & RT.		30		
STA. 1092+00 LT. & RT.		30		
STA. 1084+11, 54' RT.				1
STA. 1084+49.2, 43' RT.				1
STA. 1087+41.5, 96' RT.				1
STA. 1087+72.8, 36' LT.				1
STA. 1093+48, 33' LT.				1
STA. 1095+51, 33' RT.				1
STA. 1075+00 TO STA. 1082+29 LT.			750	
STA. 1082+65 TO STA. 1083+85 LT.			150	
STA. 1075+00 TO STA. 1081+97 RT.			700	
STA. 1082+33 TO STA. 1083+73 RT.			150	
STA. 1083+81 TO STA. 1084+50 RT.			70	
TOTAL	120	150	1820	6