



NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

	REVISIONS		
	NAME	DATE	
R.	SHAH	10/25/94	
R.	SHAH	01/14/95	
R.	SHAH	03/23/95	
R.	SHAH	04/24/95	
A.	HOUSEH	03/15/96	
A.	ABBAS	03/21/97	
Α.	ABBAS	01/20/98	
AF	RT ABBAS	04/27/98	sc
R.	BORO	01/01/07	30

ILLINOIS DEPARTMENT OF TRANSPORTATION

PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT

SCALE: VERT. NONE

DRAWN BY CHECKED BY

BD400-04 (BD-22)

07 DATE = 2/3/2007 E. NAME = Wi\diststd\bd22.dgn 07 SCALE = 50.000 '/ IN.