



NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

one manage of the control of the con				
	REVISIONS		ILLINOIS DEPARTMENT OF TRANSPORTATION	
	NAME	DATE	TELINOIS DEPARTMENT OF TRANSPORTATION	MANSF ON TATION
	R. SHAH	10/25/94		
	R. SHAH	01/14/95	PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT	
	R. SHAH	03/23/95		
	R. SHAH	04/24/95		
	A. HOUSEH	03/15/96		
	A. ABBAS	03/21/97		
	A. ABBAS	01/20/98		
	ART ABBAS	04/27/98	SCALE: VERT. NONE DRAWN BY	
[	R. BORO	01/01/07	HORIZ.	

LOT DATE = 4/11/2007 LOT SCALE = 50.000 / IN. LOT SCALE = 50.000 / IN.

BD400-04 (BD