



NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 300 (12) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE SPECIAL PROVISION "PATCHING WITH BITUMINOUS OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING BITUMINOUS MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE BITUMINOUS MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN MILLIMETERS (INCHES) UNLESS OTHERWISE SHOWN.

REVISIONS		ILLINOIS DEPARTMENT OF TRANSPORTA	
NAME	DATE	ILLINOIS DEI ANTME	IN OF THANSFORTATION
R. SHAH	10/25/94		
R. SHAH	01/14/95	DALFREDIT	DATOURIO FOR
R. SHAH	03/23/95	PAVEIVIENT	PATCHING FOR
R. SHAH	04/24/95	RITHMINIO	US SURFACED
A. HOUSEH	03/15/96		
A. ABBAS	03/21/97	PAV	/EMENT
A. ABBAS	01/20/98		
ART ABBAS	04/27/98	SCALE: VERT.	DOLLIN DV
		HORIZ.	DRAWN BY

BD400-04 (BD-22)

REVISION DATE: 04/27/98