



CONSTRUCTION STAGING

STAGE I

- 1. DRIVE TEMPORARY SHEET PILING AT THE LOCATIONS SHOWN ON PLANS.
- 2. ERECT TEMPORARY BARRIERS AS DETAILED ON THE STAGE CONSTRUCTION PLAN.
- 3. REROUTE TWO LANES OF TRAFFIC (EACH DIRECTION) TO THE EXISTING NORTHBOUND STRUCTURE.
- REMOVE EXISTING SOUTHBOUND CONCRETE DECK. PRESTRESSED CONCRETE GIRDERS, ABUTMENTS AND PIERS AS DETAILED.
- CONSTRUCT NEW PIERS AND ABUTMENTS. ERECT NEW GIRDERS AND CONSTRUCT NEW DECK AS DETAILED FOR STAGE I CONSTRUCTION.
- 6. CONSTRUCT APPROACH PAVEMENTS AND SLABS TO LIMITS AS SHOWN.

STAGE II

- 1. RELOCATE AND ERECT TEMPORARY BARRIERS AS DETAILED ON THE STAGE CONSTRUCTION PLANS.
- 2. REROUTE TWO LANES OF TRAFFIC (EACH DIRECTION) TO THE NEWLY CONSTRUCTED SOUTHBOUND STRUCTURE.
- REMOVE EXISTING NORTHBOUND CONCRETE DECK. PRESTRESSED CONCRETE GIRDERS, ABUTMENTS AND PIERS AS DETAILED.
- 4. CONSTRUCT NEW PIERS AND ABUTMENTS. ERECT NEW GIRDERS AND CONSTRUCT NEW DECK AS DETAILED FOR STAGE II CONSTRUCTION.
- 5. CONSTRUCT APPROACH PAVEMENTS AND SLABS TO LIMITS AS SHOWN.
- 6. REMOVE TEMPORARY BARRIERS AND REROUTE TRAFFIC TO THE PROPOSED LANES ON THE COMPLETED STRUCTURE.

NOTES:

- 1. FOR TEMPORARY CONCRETE BARRIER DETAILS, SEE SHEET NO. S41.
- 2. QUANTITIES FOR TEMPORARY CONCRETE BARRIER AND TYPE II BARRICADE WITH STEADY BURN LIGHT ARE SHOWN ON THE ROADWAY PLANS.

CONSTRUCTION STAGING
N.W. TOLLWAY
OVER IL 173 (F.A.P. ROUTE 303)
SECTION 129K
WINNEBAGO COUNTY
STATION 443+73.62
S.N. 101-9963 (SB) & 101-9964 (NB)
TOLLWAY S.N. 703 (NB) & 704 (SB)

