

SCHEDULE OF SIGNS

SCHEDULE OF SIGNS CONT.

SIGN	STATION	OFFSET	ALIGNMENT	SHEET	PROPOSED PANEL DIMENSIONS		SIGN PANEL TYPE 1 (SQ.FT)	SIGN PANEL TYPE 2 (SQ.FT)	SIGN PANEL TYPE 3 (SQ.FT)	WOOD SIGN SUPPORT (FOOT)	TELESCOPING STEEL SIGN SUPPORT (FOOT)	BASE FOR TELESCOPING STEEL SIGN SUPPORT (EACH)	SIGN SUPPORT SPECIAL (EACH)	STRUCTURAL STEEL SIGN SUPPORT - BREAKAWAY (POUND)	CONCRETE FOUNDATIONS (CU YD)
					WIDTH (IN)	HEIGHT (IN)									
R1-1	20+81	LT	CONNECTOR	206	36	36	9				17.5				
W4-4p	20+81	LT	CONNECTOR	206	24	12	2								
M4-5(INTERSTATE)	22+00	LT	CONNECTOR	206	24	12	2				37				
M4-5(INTERSTATE)	22+00	LT	CONNECTOR	206	24	12	2								
M4-5(INTERSTATE)	22+00	LT	CONNECTOR	206	24	12	2								
M5-1L(INTERSTATE)	22+00	LT	CONNECTOR	206	21	15	2.1875								
M6-1L(INTERSTATE)	22+00	LT	CONNECTOR	206	21	15	2.1875								
M6-1L(INTERSTATE)	22+00	LT	CONNECTOR	206	21	15	2.1875								
M1-1	22+00	LT	CONNECTOR	206	24	24	4								
M1-1	22+00	LT	CONNECTOR	206	24	24	4								
M1-1	22+00	LT	CONNECTOR	206	24	24	4								
M3-1(INTERSTATE)	22+00	LT	CONNECTOR	206	24	12	2								
M3-2(INTERSTATE)	22+00	LT	CONNECTOR	206	24	12	2								
W3-1	23+00	LT	CONNECTOR	205	30	30	6.25				16				
R2-1	25+00	RT	CONNECTOR	205	24	30	5				16				
M4-5(INTERSTATE)	26+00	LT	CONNECTOR	205	24	12	2				37				
M4-5(INTERSTATE)	26+00	LT	CONNECTOR	205	24	12	2								
M4-5(INTERSTATE)	26+00	LT	CONNECTOR	205	24	12	2								
M1-1	26+00	LT	CONNECTOR	205	24	24	4								
M3-1(INTERSTATE)	26+00	LT	CONNECTOR	205	24	12	2								
M3-2(INTERSTATE)	26+00	LT	CONNECTOR	205	24	12	2								
M1-1	26+00	LT	CONNECTOR	205	24	24	4								
M1-1	26+00	LT	CONNECTOR	205	24	24	4								
M5-1L(INTERSTATE)	26+00	LT	CONNECTOR	205	21	15	2.1875								
M5-1L(INTERSTATE)	26+00	LT	CONNECTOR	205	21	15	2.1875								
M5-1L(INTERSTATE)	26+00	LT	CONNECTOR	205	21	15	2.1875								
M2-1	26+00	RT	CONNECTOR	205	21	15	2.1875				17				
M1-5	26+00	RT	CONNECTOR	205	24	24	4								
M3-1	29+00	RT	CONNECTOR	205	24	12	2				17				
M3-3	29+00	RT	CONNECTOR	205	24	12	2								
M1-5	29+00	RT	CONNECTOR	205	24	24	4								
M1-5	29+00	RT	CONNECTOR	205	24	24	4								
M6-1L	29+00	RT	CONNECTOR	205	21	15	2.1875								
M6-1R	29+00	RT	CONNECTOR	205	21	15	2.1875								
R2-1	30+00	LT	CONNECTOR	205	24	30	5				16				
W3-1	30+00	RT	CONNECTOR	205	30	30	6.25				16				
R1-1	32+00	RT	CONNECTOR	205	30	30	6.25				17				
W4-4P	32+00	RT	CONNECTOR	205	24	12	2								
W14-1	1015+00	HI	DARLING ACCESS	203	30	30	6.25				16				
OM4-1	1017+75	LT	DARLING ACCESS	203	18	18	2.25				9	1			
OM4-1	1017+75	RT	DARLING ACCESS	203	18	18	2.25				9	1			
R11-2	1017+75	N/A	DARLING ACCESS	203	48	30		10			11	1			
R2-1	108+00	RT	EX. IL RTE. 3	206	24	30	5				15.5				
W3-5	108+50	LT	EX. IL RTE. 3	206	36	36	9				18				
W10-1	110+00	LT	EX. IL RTE. 3	205	36	DIA.	7.0685				16				
W1-7	114+75	RT	EX. IL RTE. 3	205	48	24	8				15				
M4-5(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M4-5(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M4-5(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M4-5(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M4-5(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M1-1	116+00	LT	EX. IL RTE. 3	205	24	24	4				37				
M1-5	116+00	LT	EX. IL RTE. 3	205	24	24	4								
M3-3	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M6-3	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M3-1(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M3-2(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M1-1	116+00	LT	EX. IL RTE. 3	205	24	24	4				35				
M1-1	116+00	LT	EX. IL RTE. 3	205	24	24	4								
M1-1	116+00	LT	EX. IL RTE. 3	205	24	24	4								
M1-1	116+00	LT	EX. IL RTE. 3	205	24	24	4								
M3-3(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M3-4(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	24	12	2								
M6-1R(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M6-1R(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M6-1R(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M6-1R(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M6-3(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M6-3(INTERSTATE)	116+00	LT	EX. IL RTE. 3	205	21	15	2.1875								
M3-4(INTERSTATE)	36+50	RT	PR. EXCHANGE	203	24	12	2								
M1-1	36+50	RT	PR. EXCHANGE	203	24	24	4				17				
M6-1R(INTERSTATE)	36+50	RT	PR. EXCHANGE	203	21	15	2.1875								
W14-1	37+00	LT	PR. EXCHANGE	203	30	30	6.25				16				
GS1	38+00	LT	PR. EXCHANGE	203	102	76		54					510	1.40	
W1-7	38+00	LT	PR. EXCHANGE	203	48	24	8				16				
R4-7	38+65	RT	PR. EXCHANGE	203	24	30	5					14.5	1		
M4-5(INTERSTATE)	42+50	RT	PR. EXCHANGE	203	24	12	2								

SIGN	STATION	OFFSET	ALIGNMENT	SHEET	PROPOSED PANEL DIMENSIONS		SIGN PANEL TYPE 1 (SQ.FT)	SIGN PANEL TYPE 2 (SQ.FT)	SIGN PANEL TYPE 3 (SQ.FT)	WOOD SIGN SUPPORT (FOOT)	TELESCOPING STEEL SIGN SUPPORT (FOOT)	BASE FOR TELESCOPING STEEL SIGN SUPPORT (EACH)	SIGN SUPPORT SPECIAL (EACH)	STRUCTURAL STEEL SIGN SUPPORT - BREAKAWAY (POUND)	CONCRETE FOUNDATIONS (CU YD)
					WIDTH (IN)	HEIGHT (IN)									
M4-5	42+50	RT	PR. EXCHANGE	203	24	12	2								
M1-5	42+50	RT	PR. EXCHANGE	203	24	24	4								
M1-1	42+50	RT	PR. EXCHANGE	203	24	24	4								
M5-1R	42+50	RT	PR. EXCHANGE	203	21	15	2.1875								
M5-1R(INTERSTATE)	42+50	RT	PR. EXCHANGE	203	21	15	2.1875								
M3-2(INTERSTATE)	42+50	LT	PR. EXCHANGE	203	24	12	2								
M3-4(INTERSTATE)	43+50	LT	PR. EXCHANGE	204	24	12	2								
M1-1	43+50	LT	PR. EXCHANGE	204	24	24	4				17				
M5-1L(INTERSTATE)	43+50	LT	PR. EXCHANGE	204	21	15	2.1875								
R4-7	43+95	RT	PR. EXCHANGE	204	24	30	5				14.5	1			
R2-1	47+00	LT	PR. EXCHANGE	204	24	30	5				15.5				
M4-5(INTERSTATE)	47+00	RT	PR. EXCHANGE	204	24	12	2								
M4-5	47+00	RT	PR. EXCHANGE	204	24	12	2								
M3-2(INTERSTATE)	47+00	RT	PR. EXCHANGE	204	24	12	2								
M1-1	47+00	RT	PR. EXCHANGE	204	24	24	4				17.5				
M1-5	47+00	RT	PR. EXCHANGE	204	24	24	4								
M6-1R	47+00	RT	PR. EXCHANGE	204	21	15	2.1875								
M6-1R(INTERSTATE)	47+00	RT	PR. EXCHANGE	204	21	15	2.1875								
M4-5(INTERSTATE)	50+60	LT	PR. EXCHANGE	204	24	12	2								
M1-1	50+60	LT	PR. EXCHANGE	204	24	24	4				16.5				
M3-4(INTERSTATE)	50+60	LT	PR. EXCHANGE	204	24	12	2								
M6-1L	50+60	LT	PR. EXCHANGE	204	21	15	2.1875								
W1-7	50+80	LT	PR. EXCHANGE	204	48	24	8				16				
M4-5(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M4-5(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M1-1	51+20	LT	PR. EXCHANGE	204	24	24	4				39.5				
M1-1	51+20	LT	PR. EXCHANGE	204	24	24	4								
M3-4(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M3-2(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M3-2(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M6-1L(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	21	15	2.1875								
M6-1L(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	21	15	2.1875								
M6-1L(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	21	15	2.1875								
M6-3(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	21	15	2.1875								
M3-1(INTERSTATE)	51+20	LT	PR. EXCHANGE	204	24	12	2								
M1-1	51+20	LT	PR. EXCHANGE	204	24	24	4								
M1-1	51+20	LT	PR. EXCHANGE	204	24	24	4								