

TREE REMOVAL					
STA	RT/ LT	NO.	IN	# Units	# Units
				4 to 15	15 Plus
End Section 06-1 = 266+02.9					
Begin Section 06-2 = 266+02.9					
267+56	LT	1	24		24
272+50	RT	1	6	6	
		1	5	5	
273+88	RT	1	6	6	
276+45	LT	1	6	6	
		1	13	13	
		1	25		25
279+77	RT	1	20		20
280+83	RT	1	6	6	
		1	8	8	
		1	10	10	
		1	12	12	
		1	18		18
281+95	LT	1	11	11	
286+30	LT	1	13	13	
287+57	LT	1	11	11	
290+58	RT	1	6	6	
292+74	LT	1	13	13	
293+94	LT	1	16		16
295+70	LT	15	4	60	
		5	5	25	
297+85	RT	1	11	11	
300+40	LT	1	10	10	
308+47	LT	1	10	10	
		1	6	6	
309+64	LT	1	12	12	
311+01	RT	2	6	12	
		2	8	16	
		2	10	20	
311+69	RT	1	17		17
316+98-	LT	1	10	10	
317+61		1	34		34
		4	6	24	
		2	8	16	
318+11	LT	1	16		16
		5	8	40	
318+85	LT	3	4	12	
		3	5	15	
		2	6	12	
		1	8	8	
320+00	LT	1	12	12	
		1	8	8	
		1	6	6	
320+62	LT	1	8	8	
320+92	LT	4	4	16	
		1	14	14	
321+24	RT	1	6	6	
323+33	LT	4	4	16	
328+48	RT	1	25		25
330+00	LT	1	16		16
331+10	LT	1	14	14	
336+90	LT	10	6	60	
337+77	LT	4	6	24	
338+00	LT	1	10	10	
		3	6	18	
		1	8	8	
338+26	RT	1	5	5	
341+63	LT	1	24		24
342+38.4	RT/LT	1	6	6	
		1	12	12	
343+76	RT	1	5	5	
344+67	RT	1	6	6	
345+06-	LT	1	10	10	
346+95		2	8	16	
		6	6	36	
		6	5	30	
		6	4	24	
347+41	RT	2	4	8	
		3	5	15	
		2	6	12	
349+40	LT	2	5	10	
		1	6	6	

TREE REMOVAL					
STA	RT/ LT	NO.	IN	# Units	# Units
				4 to 15	15 Plus
349+70	RT	2	5	10	
		3	6	18	
351+14	LT	1	4	4	
351+28	RT	1	6	6	
		1	7	7	
351+59	LT	1	8	8	
		1	6	6	
353+53	RT	1	6	6	
		1	8	8	
354+50	RT	1	6	6	
360+00-	LT	2	10	20	
362+25		3	8	24	
		5	6	30	
		5	5	25	
		5	4	20	
364+25	LT	4	6	24	
364+70	LT	2	5	10	
		3	6	18	
		1	8	8	
365+13	LT	2	5	10	
		2	6	12	
365+80	LT	1	8	8	
366+56	LT	1	7	7	
366+80	LT	1	10	10	
		1	8	8	
		2	6	12	
		2	5	10	
367+25	LT	3	4	12	
		1	5	5	
370+00	LT	3	6	18	
375+00	RT	1	5	5	
		3	6	18	
		2	8	16	
		1	10	10	
		1	12	12	
		1	14	14	
377+12	RT	2	4	8	
		1	6	6	
378+40	RT	1	6	6	
		2	8	16	
379+40	LT	1	10	10	
		2	8	16	
380+72	RT	1	9	9	
382+50	LT	1	10	10	
		1	8	8	
385+77	RT	1	6	6	
386+92	RT	1	6	6	
388+09	RT	1	17		17
389+06	RT	1	4	4	
		1	5	5	
		1	6	6	
390+67	LT	Sign			
395+50	LT	1	10	10	
		1	8	8	
		2	5	10	
		2	6	12	
398+54	LT	1	12	12	
399+35	RT	1	8	8	
399+50	LT	2	6	12	
		2	5	10	
400+98	RT	2	6	12	
		1	8	8	
401+60-	LT	10	6	60	
405+00		10	5	50	
		30	4	120	
405+05	RT	2	6	12	
405+40	LT	2	5	10	
		2	4	8	
406+14	RT	2	6	12	
		1	7	7	
		1	17		17
406+88	RT	2	4	8	

TREE REMOVAL					
STA	RT/ LT	NO.	IN	# Units	# Units
				4 to 15	15 Plus
408+12	RT	3	5	15	
		2	6	12	
408+76	RT	1	15	15	
409+32	RT	1	14	14	
410+23	LT	1	8	8	
		1	6	6	
410+52	LT	1	5	5	
		2	6	12	
410+96-	RT	30	4	120	
418+86		25	5	125	
		5	9	45	
		15	6	90	
		15	7	105	
		10	8	80	
412+70-	LT	1	10	10	
420+64		4	8	32	
		25	6	150	
		25	5	125	
		25	4	100	
421+50	LT	1	5	5	
		1	6	6	
428+96	RT	2	10	20	
430+29	RT	3	6	18	
430+70	RT	3	6	18	
		2	5	10	
430+94	RT	2	8	16	
		1	6	6	
431+17	RT	1	6	6	
431+25	LT	Sign			
431+60	LT	2	8	16	
		2	6	12	
431+99	RT	3	6	18	
432+20	LT	4	5	20	
		3	6	18	
		1	10	10	
		1	8	8	
		1	6	6	
		1	10	10	
432+35	RT	2	6	12	
432+62	RT	1	6	6	
432+85	RT	1	10	10	
433+45	LT	2	4	8	
		1	5	5	
		1	12	12	
		4	10	40	
433+95	LT	3	6	18	
		1	10	10	
		1	8	8	
		1	12	12	
434+25	RT	1	8	8	
434+55	LT	1	8	8	
		1	10	10	
434+79	RT	2	8	16	
		1	6	6	
434+98	RT	2	6	12	
435+19	LT	1	8	8	
		1	6	6	
435+27	RT	3	6	18	
		1	8	8	
435+50	LT	2	6	12	
435+85	LT	1	12	12	
436+20	LT	1	8	8	
		1	6	6	
437+47	LT	1	36		36
438+53	LT	1	12	12	
439+03	LT	3	6	18	
439+04	RT	1	8	8	
439+32	LT	1	4	4	
		1	5	5	
439+65	LT	1	5	5	
442+42	LT	2	5	10	

TREE REMOVAL					
STA	RT/ LT	NO.	IN	# Units	# Units
				4 to 15	15 Plus
443+37	LT	1	10	10	
		1	24		24
446+57	LT	2	4	8	
		1	5	5	
		1	6	6	
447+33	LT	2	4	8	
		1	5	5	
448+00	LT	1	6	6	
449+25	RT	1	14	14	
450+22	RT	1	12	12	
450+38	LT	5	5	25	
450+87	RT	1	14	14	
		1	10	10	
453+03	LT	1	24		24
453+51	LT	1	30		30
483+74-	LT	5	5	25	
484+95		4	6	24	
		2	8	16	
		1	12	12	
		1	10	10	
		1	11	11	
487+95	LT	1	8	8	
489+60	LT	3	6	18	