

CONTROLLER #23 (1 OF 2)

MESSAGE AREA		
A	B	C
A1	400	480
A2	400	480
A3	250	480
A4	250	480
A5	250	480
A6	250	480
A7	250	480
A8	250	480
A9	250	480
B5	250	480
B6	250	480
B7	250	480
B8	250	480
B9	400	480
B10	400	480
B11	400	480
B12	400	480
B13	400	480
D1	250	480
D2	250	480
D3	250	480
D4	250	480
D5	250	480
D6	250	480
D7	250	480
D8	250	480
D9	250	480
D10	250	480
D11	250	480
D12	250	480
D13	250	480
D14	400	480
D15	400	480
D16	400	480
E1	400	480
E2	400	480
E3	400	480
E4	250	480
E5	250	480
E6	250	480
E7	250	480
E8	250	480
E9	250	480
E10	400	480
EX41	400	480
EX43	400	480
EX45	400	480
EX47	400	480
EX52	400	480
EX53	400	480
EX55	400	480
EX57	400	480
EX59	400	480
EX61	400	480
F1	400	480
F2	400	480
F3	400	480
F4	250	480
F5	250	480
F6	250	480
F7	250	480
F8	250	480
F9	250	480
F10	400	480
L13	250	480
L14	250	480
L15	250	480
NM152	400	480
NM153	400	480
NM154	400	480
NM158	400	480
NM160	400	480
NM162	400	480
NM164	400	480
NM165	400	480
NM166	400	480
NM168	400	480
NM170	400	480
SM149	400	480
SM150	400	480
SM151	400	480
SM155	400	480
SM156	400	480
SM157	400	480
SM159	400	480
SM161	400	480
SM163	400	480
WX44	400	480
WX46	400	480
WX48	400	480
WX49	400	480
WX50	400	480
WX51	400	480
WX54	400	480
WX56	400	480
WX58	400	480

CONTROLLER #23 (2 OF 2)

MESSAGE AREA		
A	B	C
WX60	400	480
WX62	400	480
WX63	400	480

CONTROLLER #24		
MESSAGE AREA		
A	B	C
A1	400	480
A2	400	480
A3	400	480
A4	250	480
A5	250	480
A6	250	480
A7	250	480
A8	250	480
B1	250	480
B2	250	480
B3	250	480
B4	250	480
B5	400	480
B6	400	480
B7	400	480
SM177	400	480
SM179	400	480
SM181	400	480
SM183	400	480
SM185	400	480
SM187	400	480
SM189	400	480
SM191	400	480
SM192	400	480
X1	400	480
X2	400	480
X3	400	480
X4	400	480
X5	400	480
X6	400	480
X7	400	480

CONTROLLER #25		
MESSAGE AREA		
A	B	C
C1	400	480
C2	400	480
C3	400	480
C4	250	480
C5	250	480
C6	250	480
C7	250	480
C8	250	480
C9	250	480
C10	250	480
C11	250	480
D1	250	480
D2	250	480
D3	250	480
D4	250	480
D5	250	480
D6	250	480
D7	250	480
D8	250	480
D9	400	480
D10	400	480
D11	400	480
D12	400	480
D13	400	480
NM176	400	480
NM178	400	480
NM180	400	480
NM182	400	480
NM184	400	480
NM186	400	480
NM188	400	480
NM190	400	480
X8	400	480
X9	400	480
X10	400	480
X11	400	480
X12 A&B	250/250	480

CONTROLLER #26

MESSAGE AREA		
A	B	C
A1	250	480
A2	400	480
A3	400	480
A4	400	480
A5	400	480
B1	400	480
B2	400	480
B3	400	480
B4	400	480
B5	250	480
C1	250	480
C2	400	480
C3	400	480
C4	400	480
C5	400	480
D1	400	480
D2	400	480
D3	400	480
D4	400	480
D5	250	480
X1	400	480
X2	400	480
X3	400	480
X4	400	480
X5	400	480
X6	250	480
X7	400	480
X8	400	480
X9	400	480
X10	400	480
X11	400	480

CONTROLLER #27 (1 OF 2)

MESSAGE AREA		
A	B	C
A4	250	480
A5	250	480
A6	250	480
A7	250	480
A8	250	480
A9	250	480
A10	250	480
A11	250	480
A12	250	480
A13	250	480
A14	250	480
A15	250	480
A16	400	480
A17	400	480
A18	400	480
A19	400	480
A20	400	480
A21	400	480
A22	400	480
A23	400	480
B1	400	480
B2	EX.AL-TB	480
B3	400	480
B4	EX.AL-TB	480
B5	EX.AL-TB	480
B6	EX.AL-TB	480
B7	EX.AL-TB	480
B8	EX.AL-TB	480
B9	EX.AL-TB	480
B10	EX.AL-TB	480
B11	400	480
B12	400	480
C1	EX.AL-TB	480
C2	EX.AL-TB	480
C3	EX.AL-TB	480
C4	EX.AL-TB	480
C5	EX.AL-TB	480
C6	EX.AL-TB	480
C7	EX.AL-TB	480
C8	EX.AL-TB	480
C9	EX.AL-TB	480
C10	EX.AL-TB	480
C11	EX.AL-TB	480
C12	EX.AL-TB	480
C13	EX.AL-TB	480
C14	EX.AL-TB	480
C15	EX.AL-TB	480
D2	400	480
D3	400	480
D4	250	480
D5	250	480
D6	250	480
D7	250	480
D8	250	480
D9	250	480
D10	250	480
D11	EX.AL-TB	480
D12	EX.AL-TB	480
E1	400	480
EM13 A&B	400/250	480
EM15 A&B	400/250	480
EM17	400	480
EM19	400	480
EM21	400	480
EM23	400	480
F24	250	480
F25	250	480
F26	250	480
F27	250	480
F28	250	480
F30	250	480
F29	250	480
F31	250	480
F32	250	480
F33	250	480
F34	400	480
F35	400	480
F36	400	480
F37	400	480
F38	400	480
F39	400	480
SM1	EX.AL-TB	480
SM10	400	480
SM11	EX.AL-TB	480
SM12	400	480
SM13	400	480
SM14	400	480
SM15	400	480
SM2	EX.AL-TB	480
SM3	EX.AL-TB	480
SM4	EX.AL-TB	480
SM5	EX.AL-TB	480
SM6	EX.AL-TB	480
SM7 A&B	EX.AL-TB	480
SM8	EX.AL-TB	480
SM9	400	480

CONTROLLER #27 (2 OF 2)

MESSAGE AREA		
A	B	C
SM292 A&B	EX.AL-TB	480
WM14	400	480
WM16	400	480
WM18	400	480
WM20	400	480
WM22	400	480
WM9	400	480

CONTROLLER #28 (1 OF 2)

MESSAGE AREA		
A	B	C
A24	400	480
A25	400	480
D1	250	480
E1	EX.AL-TB	480
E2	EX.AL-TB	480
E3	EX.AL-TB	480
E4	EX.AL-TB	480
E5	EX.AL-TB	480
E6	EX.AL-TB	480
E7	EX.AL-TB	480
E8	EX.AL-TB	480
E9	EX.AL-TB	480
E10	EX.AL-TB	480
E11	EX.AL-TB	480
E12	EX.AL-TB	480
E13	EX.AL-TB	480
E14	EX.AL-TB	480
E15	EX.AL-TB	480
E16	EX.AL-TB	480
E17	EX.AL-TB	480
E18	EX.AL-TB	480
E19	EX.AL-TB	480
E20	EX.AL-TB	480
EM28 A&B	EX.AL-TB	480
EM30	400	480
EM32	400	480
EM33	400	480
EM35 A&B	400/250	480
EM43	400	480
EM45	400	480
EM47	400	480
EM49	400	480
EM51	400	480
F1	400	480
F2	400	480
F3	400	480
F4	400	480
F5	400	480
F6	400	480
F7	400	480
F8	400	480
F9	400	480
F10	400	480
F11	400	480
F12	400	480
F13	400	480
F14	250	480
F15	250	480
F16	250	480
F17	250	480
F18	250	480
F19	250	480
F20	250	480
F21	250	480
F22	250	480
F23	250	480
G1	250	480
G2	250	480
G3	400	480
G4	400	480
G5	250	480
G6	250	480
G7	250	480
G8	400	480
G9	400	480
G10	400	480
G11	400	480
G12	400	480
G13	400	480
H1	EX.AL-TB	480
H2	EX.AL-TB	480
H3	EX.AL-TB	480
H4	EX.AL-TB	480
H5	EX.AL-TB	480
H6	EX.AL-TB	480
H7	400	480
H8	400	480
NM1	EX.AL-TB	480
NM2	EX.AL-TB	480
NM3	EX.AL-TB	480
NM4	EX.AL-TB	480
NM5	EX.AL-TB	480
NM6	EX.AL-TB	480
NM7	EX.AL-TB	480
NM8 A&B	EX.AL-TB	480
NM9	EX.AL-TB	480
NM10	EX.AL-TB	480
NM11	EX.AL-TB	480
NM12	EX.AL-TB	480
NM13	EX.AL-TB	480
NM14	EX.AL-TB	480
NM15	EX.AL-TB	480
NM16	EX.AL-TB	480
NM17	EX.AL-TB	480
NM18	EX.AL-TB	480
WM25	EX.AL-TB	480

CONTROLLER #28 (2 OF 2)

MESSAGE AREA		
A	B	C
WM27	400	480</