

See Standard 630001 for details of

Use plate washer F at all posts.

The bearing plate K shall be held in position by (2) two eight penny nails driven into the post and bent over

All dimensions are in millimeters (inches)

ANDAND USIUII-UZ			F.A.• RTE.	SECTION	COUNTY	TOTAL SHEETS	SHEET NO.	
ERMINAL TYPE 2			VAR	•	•	17	12	
4-1-06 (SHEET 1 OF 1)					CONTRACT	NO. 7	2620	
TS	STA.	TO STA.		ILLINOIS FED. AID PROJECT				
DC CARLE (CUARRAN								