

# EARTHWORK SCHEDULE

LOCATION	EARTH	EARTH	EMBANK (FILL) CU YD	EARTH WORK
	EXC	EXC ADJ		BALANCE
	(CUT)	SHRINK		WASTE (+)
	25%		SHORTAGE (-)	
	CU YD	CU YD	CU YD	CU YD
801+00 - 807+00	358	269	477	-209
807+00 - 813+00	1581	1185	122	1064
813+00 - 819+00	2785	2089	76	2013
819+00 - 825+00	1874	1406	212	1193
825+00 - 831+00	394	295	1224	-929
831+00 - 837+00	415	312	792	-480
837+00 - 843+00	423	317	513	-196
843+00 - 849+00	431	323	893	-570
849+00 - 855+00	302	227	459	-233
855+00 - 861+00	337	253	1154	-901
861+00 - 867+00	448	336	961	-625
867+00 - 873+00	753	565	474	90
873+00 - 879+00	380	285	258	27
879+00 - 885+00	401	301	510	-209
885+00 - 891+00	515	386	502	-116
891+00 - 897+00	445	334	342	-9
897+00 - 903+00	439	330	605	-275
903+00 - 909+00	429	322	406	-84
909+00 - 915+00	324	243	773	-530
915+00 - 921+00	596	447	581	-134

LOCATION	EARTH	EARTH	EMBANK (FILL) CU YD	EARTH WORK
	EXC	EXC ADJ		BALANCE
	(CUT)	SHRINK		WASTE (+)
	25%		SHORTAGE (-)	
	CU YD	CU YD	CU YD	CU YD
921+00 - 927+00	776	582	330	251
927+00 - 933+00	304	228	679	-451
933+00 - 939+00	427	320	557	-236
939+00 - 945+00	377	283	550	-267
945+00 - 951+00	439	330	242	88
951+00 - 957+00	464	348	179	168
957+00 - 963+00	670	503	734	-231
963+00 - 969+00	935	702	290	412
969+00 - 975+00	610	458	202	256
975+00 - 981+00	406	305	631	-326
981+00 - 987+00	950	713	363	349
987+00 - 993+00	487	365	241	124
993+00 - 999+00	652	489	93	397
999+00 - 1005+00	409	307	91	216
1005+00 - 1011+00	519	389	234	155
1011+00 - 1017+00	402	301	236	65
1017+00 - 1019+00	28	21	16	5
<b>TOTAL</b>	<b>22487</b>	<b>16865</b>	<b>17002</b>	<b>-137</b>