



START WEST CONNECTOR EARTHWORK,
 STA. 801+05.61

KEY FOR EARTHWORK	
	UC = UNCLASSIFIED CUT
	CF = COMPACTED FILL
	UF = UNCOMPACTED FILL

G:\airport\A07T030 TP EARTHWORK DSN\Sections P1-P2.dwg, 4/21/2008 11:44:06 AM, jefm