

PATCHING SCHEDULE

DIR	STATION to STATION	LOCATION DL/PL	DIMENSIONS		CLASS A PATCHES, 13"				SAW CUTS	TIE BARS 3/4"	PATCHING REINFORCEMENT
			LTH	WTH	TY-I	TY-II	TY-III	TY-IV			
			FT	FT	SO YDS	SO YDS	SO YDS	SO YDS			
EB	1031+42 - 1031+48	DL	6	12		8			60		8
EB	1031+42 - 1031+48	PL	6	12		8			60		8
EB	1049+65 - 1049+71	DL	6	12		8			60		8
EB	1064+98 - 1065+13	DL	15	12			20		78		20
EB	1076+20 - 1076+32	DL	12	12			16		72		16
EB	1090+13 - 1090+43	DL	30	12				40	108	15	40
EB	1091+42 - 1091+72	DL	30	12				40	108	15	40
EB	1111+69 - 1111+78	DL	9	12		12			66		12
EB	1111+69 - 1111+75	PL	6	12		8			60		8
EB	1128+52 - 1128+58	DL	6	12		8			60		8
EB	1128+52 - 1128+58	PL	6	12		8			60		8
EB	1130+01 - 1130+07	DL	6	12		8			60		8
EB	1130+01 - 1130+07	PL	6	12		8			60		8
EB	1136+18 - 1136+24	DL	6	12		8			60		8
EB	1161+33 - 1161+39	DL	6	12		8			60		8
EB	1162+01 - 1162+07	DL	6	12		8			60		8
EB	1162+92 - 1162+98	DL	6	12		8			60		8
EB	1185+57 - 1185+65	DL	8	12		11			64		11
EB	1187+08 - 1187+28	DL	20	6		13			64		13
EB	1188+40 - 1188+55	DL	15	12			20		78		20
EB	1189+23 - 1189+33	DL	10	6		7			44		7
EB	1192+83 - 1192+93	DL	10	6		7			44		7
EB	1196+90 - 1196+98	DL	8	12		11			64		11
EB	1198+77 - 1198+87	DL	10	6		7			44		7
EB	1202+21 - 1202+31	DL	10	6		7			44		7
EB	1220+02 - 1220+14	DL	12	6		8			48		8
EB	1222+85 - 1223+00	DL	15	6		10			54		10
EB	1226+90 - 1227+60	DL	70	12				93	188	35	93
EB	1231+37 - 1231+43	DL	6	6	4				36		4
EB	1290+18 - 1290+26	DL	8	12		11			64		11
EB	1291+41-1291+56	DL	15	12			20		78		20
EB	1294+90 - 1295+15	DL	25	12				33	98	13	33
EB	1310+88 - 1310+96	DL	8	6		5			40		5
EB	1362+31 - 1362+43	DL	12	6		8			48		8
SUBTOTAL (EB1)					4	213	76	206	2252	78	499

DL/PL INDICATES DRIVING LANE OR PASSING LANE.