



District 2 Horizontal & Vertical Control Setup

1 The following outlines the steps for setting up the files to be used with the District 2 “HorzVertControl.mvba” to create the HVC tables and alignment descriptions.

- 1) Copy the “HorzVertControl.mvba” and “Horizontal_and_Vertical_Control.pdf” files to “....\IDOT_CONNECT\Configuration\Organization-Civil\IDOT_Standards\Macros” folder.



- 2) Copy the “CogoAlignmentDescriptionASCII.xml” and “D2_StationOffsetNorthingEastingElevationFeature_CSV.xml” files to “....\IDOT_CONNECT\Configuration\Organization-Civil\IDOT_Standards\Reports” folder.



Where is the drive location of the “IDOT_CONNECT” folder.

District 2 Horizontal & Vertical Control Setup

- 3) The "*HorzVertControl.mvba*" application is activated by using the following key-in command:

vba run [HorzVertControl]modStart.Start

- 4) Refer to the "*Horizontal_and_Vertical_Control.pdf*" file for the steps to use this application.