



ALIGNMENT COORDINATES - IL 9			
IL 9	STATION	N	E
PC	1184+16.17	1,425,215.43	2,085,103.79
PI	1193+20.47	1,424,311.87	2,085,140.30
PT	1201+48.90	1,423,648.30	2,085,754.66
POT	1205+21.84	1,423,374.64	2,086,008.03
POT	1219+54.00	1,422,323.73	2,086,981.00
PC	1223+10.10	1,422,062.43	2,087,222.93
PI	1227+00.00	1,421,776.32	2,087,487.81
PT	1230+85.11	1,421,571.66	2,087,819.68
POT	1239+59.60	1,421,112.63	2,088,564.00
PC	1254+94.99	1,420,305.45	2,089,870.10
PI	1258+77.69	1,420,104.26	2,090,195.65
PT	1263+31.52 AH=1262+55.89 BK	1,419,995.47	2,090,562.56
POT	0+00.00 AH=1269+77.10 BK	1,419,811.94	2,091,181.50
POT	7+00.00	1,419,612.94	2,091,852.62

ALIGNMENT COORDINATES - TR 3000 E			
STATION	N	E	
POT	10+00.00	1,423,423.68	2,085,962.62
POT	9+80.36	1,423,409.01	2,085,949.57
POT	9+07.47	1,423,354.53	2,085,901.14

ALIGNMENT COORDINATES - TR 2500 N			
STATION	N	E	
POT	10+00.00	1,420,760.38	2,089,133.98
POT	9+70.53	1,420,749.74	2,089,106.50
POT	9+21.82	1,420,732.16	2,089,061.06

ALIGNMENT COORDINATES - TR 000 E			
STATION	N	E	
POT	10+00.00	1,419,811.94	2,091,181.50
POT	8+88.60	1,419,700.54	2,091,182.47