

SCHEDULE OF QUANTITIES

28000250 TEMPORARY EROSION CONTROL SEEDING

POUND	LOCATION	*6 Applications X 100 Lbs / Acre			
<u>US 20 BR</u>					
355	Sta 265 + 21	-	281 + 48	LT	
376	Sta 265 + 21	-	280 + 94	RT	
222	Sta 282 + 48	-	302 + 30	LT	
301	Sta 283 + 02	-	302 + 30	RT	
<u>1,255</u>	TOTAL				

28000400 PERIMETER EROSION BARRIER

FOOT	LOCATION				
<u>US 20 BR</u>					
200	Sta 265 + 50	-	267 + 50	LT	
300	Sta 277 + 00	-	280 + 00	LT	
450	Sta 276 + 50	-	281 + 00	RT	
<u>1,150</u>	Sta 284 + 50	-	296 + 00	RT	
<u>2,100</u>	TOTAL				

28000500 INLET AND PIPE PROTECTION

EACH	LOCATION				
<u>US 20 BR</u>					
3	As Needed & Directed by the Resident				
<u>3</u>	TOTAL				

31100910 SUB-BASE GRANULAR MATERIAL, TYPE A 12"

SQ YD	LOCATION				
<u>US 20 BR</u>					
183.3	Sta 267 + 71	-	270 + 00	Start Widening RT	
1,088.0	Sta 270 + 00	-	275 + 64		
694.4	Sta 275 + 64	-	278 + 30		
828.4	Sta 278 + 30	-	280 + 81	End Widening RT	
43.7	Sta 282 + 54	-	283 + 05	Start Widening LT	
375.4	Sta 283 + 05	-	285 + 54		
219.4	Sta 285 + 54	-	287 + 99	End Widening LT	
<u>2,406.3</u>	Sta 283 + 83	-	296 + 22	Widening RT	
<u>5,838.9</u>	TOTAL				

35101400 AGGREGATE BASE COURSE, TYPE B

TON	LOCATION	*Under HMA Shoulders for Staging			
<u>US 20 BR</u>					
36.4	Sta 265 + 21	-	265 + 81	LT	
1,205.8	Sta 265 + 81	-	280 + 07	LT	
88.2	Sta 286 + 25	-	287 + 99	LT	
707.4	Sta 287 + 100	-	296 + 34	LT	
<u>266.4</u>	Sta 296 + 34	-	299 + 00	LT	
<u>2,304.2</u>	TOTAL				

40600895 CONSTRUCTING TEST STRIP

EACH	LOCATION				
<u>US 20 BR</u>					
1	As Needed & Directed by the Resident (for Binder Course)				
<u>1</u>	TOTAL				