

CONCRETE COLLAR


** PIPE UNDERDRAIN/PIPE CULVERT TO BE FIELD LOCATED BY THE CONTRACTOR AND AS DIRECTED BY THE ENGINEER


GENERAL

- 1. CARE MUST BE TAKEN TO PREVENTDEBRIS FROM ENTERING THE PIPE CULVERT.
 ALL DEBRIS WHICH ENTERS THE PIPE CULVERT MUST BE REMOVED. THE PIPE CULVERT MUST BE LEFT CLEAN AND UNOBSTRUCTED UPON COMPLETION OF THE CONTRACT.
- 2. CARE MUST BE TAKEN TO PREVENT ANY PART OF THE NEW PIPE CONNECTION FROM PROJECTING INTO THE EXISTING SEWER.

BASIS OF PAYMENT

THE WORK FOR CONNECTING A PROPOSED PIPE CULVERT TO AN EXISTING PIPE CULVERT AS SHOWN IN THIS DETAIL SHALL BE PAID FOR AT THE CONTRACT UNIT PRICE PER EACH AS CONCRETE COLLAR WHICH PRICE SHALL INCLUDE ALL EQUIPMENT, LABOR, AND MATERIALS REQUIRED TO CONSTRUCT THE PROPOSED CONCRETE COLLAR.





CONSTRUCTION SEQUENCE:

- 1. CUT THE EXISTING END OF THE PIPE SO AS TO PRESENT A FLUSH BUTT JOINT. BRUSH AND CLEAN
- 2. APPLY THE MASTIC JOINT SEALANT TO THE FIRST 6" OF EACH PIPE.
- 4. CUT A PIECE OF SHEET METAL GAGE NO. 0.0418 18" WIDE BY THE OUTSIDE CIRCUMFERANCE
- 5. WRAP THE SHEET METAL AROUND THE PIPES. 9" ON EACH SIDE OF THE JOINT, STARTING AT THE TOP OF THE PIPE.
- MASTIC JOINT SEALANT BETWEEN THE LAP.

- 7. PLACE TWO METAL BANDS AROUND THE SHEET METAL AND TIGHTEN.
- 8. WIPE OFF ANY EXCESS MASTIC JOINT SEALANT THAT OOZES OUT FROM BETWEEN THE SHEET METAL AND THE PIPES.
- 9. PLACE CLASS SI CONCRETE AROUND THE JOINT.

ILLINOIS DEPARTMENT OF TRANSPORTATION **CONCRETE COLLAR AND INLET BOX DETAILS**

SCALE: NONE DATE 4/18/2005

DRAWN BY DN CHECKED BY IR

- 3. BUTT THE PIPES TOGETHER LEAVING A MINIMUM OF $12^{\prime\prime}$ \times $6^{\prime\prime}$ DEEP EXCAVATION UNDER AND AROUND EACH PIPE END.
- OF THE PIPE PLUS 3" LONG.
- 6. LAP THE SHEET METAL AT LEAST 3" AT THE TOP OF THE PIPE AND PLACE THE