

"W" = Top bars spacing + 4"


R-27

7-1-10

FILE NAME = DESIGNED REVISED Allen Henderson & Associates, Inc. TEMPORARY CONCRETE BARRIER FOR STAGE CONSTRUCTION	
	TOTAL SHEET
CHECKED - REVISED - Civil and Structural Engineers Springfield II	8 54 39
PLOT SCALE =DRAWN -REVISED -REVISED -Structural Engineers op ingred, in: 62703 Phone: (217)544-8033IL. Design FirmSTRUCTURE NO.	
PLOT DATE = CHECKED REVISED No. 184-001907 SHEET NO. 7 OF 22 SHEETS ILLINOIS FED. AID PROJECT	

NOTES

Detail I - With Bar Splicer or Couplers: Connect one (1) 1'' x 7' 'x 'W'' steel f2 to the top layer of couplers with $2 - \frac{5}{8}'' \phi$ bolts screwed to coupler at approximate *Q* of each barrier panel. Detail II - With Extended Reinforcement Bars: Connect one (1) 1" x 7" x "W" steel L to the concrete slab or concrete wearing surface with 2- ${}^{5}_{8}$ " ϕ Expansion Anchors or cast in place inserts spaced between the top layer of reinforcement at approximate ∉ of each barrier panel. Cost of anchorage is included with Temporary Concrete Barrier. The I'' x 7'' x 'W'' plate shall not be removed until stage II construction forms and all reinforcement bars are in place and the concrete is ready



* Required only with Detail II

TEMPORARY CONCRETE BARRIER FOR STAGE CONSTRUCTION S.N. 082-0241 (NB) & S.N. 082-0242 (SB)