
SYMBOL

* [TEM] *


ITEM

CONTRACT #7240



HAY OR STRAW BALE TEMPORARY DITCH CHECK

(TYPICAL & SEE GENERAL NOTES FOR SUBSTITUTION TO FLUSH RIPRAP DITCH CHECK)



NOTE 1: BALES SHALL EXTEND FAR ENOUGH UP THE

BALES.

SLOPES TO ALLOW O.3m (1') OVERTOPPING TO

AVOID ERODING AROUND THE EDGES OF THE

LEGEND FOR STORM WATER POLLUTION PREVENTION PLAN

AGGREGATE (EROSION CONTROL)
[STONE DUMPED RIPRAP DITCH CHECKS: Height = 0.6m (2')]

TEMPORARY DITCH CHECKS

(HAY OR STRAW BALE DITCH CHECKS OR APPROVED SUBSTITUTION)

INLET PIPE PROTECTION (I&PP)
(HAY OR STRAW BALE DITCH CHECKS OR APPROVED SUBSTITUTION)

EARTH EXCAVATION FOR EROSION CONTROL (SEDIMENT BASINS)

PRESERVE EXISTING TREES, WOODLANDS, AND UNDERSTORY (OUTSIDE CONSTRUCTION LIMITS)

EROSION CONTROL FENCE

ITEM PLACED AT BEGINNING OF CONSTRUCTION (Requirement)

ITEM PLACED AS DIRECTED BY ENGINEER (When required by situation)

DIRECTION OF OVERLAND FLOW

GENERAL NOTES:

All items shall be constructed as shown on this sheet, on Standard 280001, and as directed by the Engineer.

The symbology on the STORM WATER POLLUTION PREVENTION PLAN sheets does not represent the size or quantity of bales, for number of bales refer to details and notes shown on this sheet and/or as directed by the Engineer.

THE CONTRACTOR SHALL INSTALL DITCH CHECKS AS DIRECTED BY THE ENGINEER. IF THE ENGINEER ELECTS TO UTILIZE FLUSH RIPRAP DITCH CHECKS IN LIEU OF TEMPORARY DITCH CHECKS AS SHOWN ON THE FOLLOWING PLAN SHEETS, THE SPACING SHOULD BE DOUBLED.

NOTE 2: RIPRAP SHALL EXTEND FAR ENOUGH UP THE SLOPES TO ALLOW 0.3m (1') OVERTOPPING TO AVOID ERODING AROUND THE EDGES OF THE RIPRAP.

NOTE 3: ENDS SHALL BE TIED INTO SLOPES.

NAME DATE

STORM WATER POLLUTION
PREVENTION PLAN

SCALE: NONE
DATE: JANUARY 2007

DRAWN BY: SGL CHECKED BY: FML

STRINGS OR

HAY OR STRAW BALE

(TYPICAL ELEVATION)

WIRES