


\* Order a80(E), a81(E) and a85(E) bars full length.  
Cut to fit skew and use remainder of bars in opposite end.



**PLAN**

(Stage 1 and Stage 2 shown. Stage 3 similar to Stage 2)

**NOTES:**

1. See sheet SB17 for superstructure details and Bill of Material.
2. Bars indicated thus 3x10-#5 etc. indicates 3 lines of bars with 10 lengths per line.
3. See sheet SB17 for parapet reinforcement.
4. See sheet SB18 for median barrier reinforcement.
5. See sheet SB18 for Section A-A.
6. See sheet SB53 for Bar Splicer Assembly to be used at Stage 1 construction joint for a83(E)

**benesch**  
engineers · scientists · planners

Alfred Benesch & Company  
205 North Michigan Avenue, Suite 2400  
Chicago, Illinois 60601  
312-565-0450 Job No. 10056

FILE NAME =  
0900167.68620.15.dkp1.dgn

USER NAME = mbecker  
DESIGNED - MFB  
CHECKED - MRB  
PLOT SCALE =  
DRAWN - PRT  
PLOT DATE = 7/17/2012  
CHECKED - MRB

DESIGNED - MFB  
CHECKED - MRB  
DRAWN - PRT  
CHECKED - MRB

REVISED -  
REVISED -  
REVISED -  
REVISED -

**STATE OF ILLINOIS  
DEPARTMENT OF TRANSPORTATION**

**SUPERSTRUCTURE  
STRUCTURE NO. 090-0167**

SHEET NO. SB15 OF SB65 SHEETS

F.A.I. RTE.	SECTION	COUNTY	TOTAL SHEETS	SHEET NO.
74	90-[14R;14HB-4,14,14HVB]BR	TAZEWELL	2433	1926
CONTRACT NO. 68620				
ILLINOIS FED. AID PROJECT				