


GENERAL NOTE:

THIS WORK SHALL CONSIST OF THE REMOVAL AND REPLACEMENT OF DETECTOR LOOPS AND AXLE DETECTORS (PIEZOCABLE SENSOR). THE DETECTOR LOOPS AND AXLE DETECTORS SHALL BE REMOVED WITH THEIR ELECTRIC CABLE ALL THE WAY TO THE EXISTING CABINET CONNECTION, AND REPLACED IN THE SAME MANNER USING THE EXISTING CONDUIT, HANDHOLE, AND GULFBOX JUNCTION.



NOTE:
THIS ARRANGEMENT CAN BE USED ONLY WITH NEW PAVEMENT CONSTRUCTION.

ALTERNATE SENSOR CABLE INSTALLATION


SENSOR ASSEMBLY INSTALLATION PROCEDURE:

1. USING A CHALK LINE, MARK THE SENSOR TRENCH OUTLINE ON THE PAVEMENT. SEE SYSTEM LAYOUT DRAWING FOR SENSOR LOCATIONS.
2. SAW CUT AROUND THE TRENCH PERIMETER TO A DEPTH OF 1/2".
3. SAW CUT THE 3/8" x 1" DEPTH. SENSOR CABLE SLOT THE THE EDGE OF THE PAVEMENT.
4. REMOBE EXISTING PAVEMENT TO A DEPTH OF 1/2" WITHIN THE SAW CUT TRENCH PERIMETER.
5. THOROUGHLY CLEAN THE TRENCH OF ALL DEBRIS, DUST, ETC.
6. PLACE SENSOR ASSEMBLY IN THE TRENCH. ADJUST THE #10-32 LEVELING SCREWS UNTIL THE TOP OF THE SENSOR ASSEMBLY IS EVEN WITH THE PAVEMENT SURFACE. (NO HIGHER THAN 1/16")
7. THOROUGHLY MIX LARGE CAN OF ENCAPSULANT.

8. ADD HARDENER & MIX THOROUGHLY.
9. POUR ENCAPSULANT AROUND SENSOR TRYING NOT TO DISTURB SENSOR.
10. 3 TO 5 POUND WEIGHT MAY HAVE TO BE USED TO STOP FLOATING.
11. FILL TRENCH WITH MIXTURE UNTIL FLUSH WITH THE SURFACE OF PAVEMENT. TROWEL AS REQUIRED.
12. LET EPOXY CURE UNTIL HARD.
13. GRIND PERIMETERS IF NEEDED TO REMOVE HIGH OR ROUGH SPOTS.

NOTE: SENSOR CAN BE BENT SLIGHTLY TO CONFORM TO ROADWAY.

REFERENCE: INSTALLATION MANUAL #1050527



W.B.

BIT. SURF. W/P.C.C. BASE FULL REIN.


INTERSTATE 80, 3 MILES EAST OF FAS 268 (MARSEILLES) INTERCHANGE. LASALLE COUNTY

E.B.

DETECTOR LOOP INSTALLATION


LOOP IN P.C.C. PAVEMENT

FILL SLOT WITH 2-COMPONENT EPOXY



LOOP IN ASPHALT

FILL SLOT WITH 2-COMPONENT EPOXY



DETECTOR LOOP LEAD-IN DETAIL

DRILL HOLE IN PAVEMENT 6" - 10" FROM EDGE. INSERT CONDUIT AND FILL WITH TWO PART MASONRY EPOXY.

