



- NOTES:**
- SEE SHEETS GI-1 AND GI-2 FOR INSTRUMENTATION SYMBOL LIST, ABBREVIATIONS, AND GENERAL NOTES.
 - WHEN THIS RELAY IS ENERGIZED, THE FLOAT LEVELING SYSTEM WILL CONTROL PUMP OPERATION. REFER TO NOTE 2 ON SHEET CPD-6 FOR ADDITIONAL DETAILS.
 - PAVEMENT FLOODED FLOAT SWITCH (LSH050) IS INSTALLED IN MANHOLE LOCATED ADJACENT TO ROADWAY. REFER TO ELECTRICAL SITE PLAN FOR MANHOLE LOCATION.
 - ALL INTERCONNECTING WIRES/CABLES BETWEEN PANELS SHALL TERMINATE ON TERMINAL STRIPS AND SHOULD NOT BE DIRECTLY CONNECTED TO DEVICES LOCATED IN THE PANELS.

MFP-1 FLOAT CALL

MFP-2 FLOAT CALL

MFP-3 FLOAT CALL

LFP-4 FLOAT CALL

HIGH WATER ALARM FOR AEGIS SYSTEM

LOW WATER ALARM FOR AEGIS SYSTEM

CONTROL PANEL CP47 POWER FAILURE

REFER TO SHEET E-10A